

Lesen Sie die Gebrauchsanleitung von Montage und Anwendung sorgfältig durch. Die Sicherheitsfunktion des Artikels könnte sonst beeinträchtigt werden, Bewahren Sie die Anleitung für späteres Nachschlagen auf.

0+

Sicherheitshinweise:

- **Achtung! Bei Nichtbeachtung Sturz- und Verletzungsgefahr**
- Verwenden Sie den Artikel nur zu dem vorgesehenen Zweck.
- Bei Anzeichen von Mängeln nicht verwenden.
- Achtung: Benutzung unter unmittelbarer Aufsicht von Erwachsenen. Lassen Sie Kinder nicht unbeaufsichtigt damit spielen. Vorsicht bei der Verwendung! Es ist Geschick erforderlich, um Stürze oder Zusammenstöße zu vermeiden, die zu Verletzungen führen können.
- Das maximale Benutzergewicht beträgt 100 kg.
- Verwenden Sie den Artikel nur im Innenbereich.
- Verwenden Sie den Artikel nur auf trockenem, ebenem und nicht glattem Untergrund.
- Stellen Sie sicher, dass um den Artikel ausreichend Freiraum befindet. In diesem Freiraum dürfen sich keine Gegenstände oder Hindernisse befinden.
- Spitze oder scharfe Gegenstände können den Artikel beschädigen. Stellen Sie sicher, dass der Spielbereich frei von diesen Gegenständen ist.

Reinigung:

Reinigen Sie den Artikel mit einem feuchten, weichen Tuch. Verwenden Sie keine aggressiven Reiniger. Lassen Sie den Artikel gut trocknen, bevor Sie ihn wieder verwenden.

Aufbewahrung:

Bewahren Sie den Artikel an einem trockenen Ort auf. Schützen Sie den Artikel vor direkter Sonneneinstrahlung. Bewahren Sie den Artikel für Kinder unzugänglich auf.

Bitte Kaufbelege, Gebrauchsanleitung und Artikelnummer aufbewahren. Gewährleistungsansprüche oder Ansprüche aus Garantieverprechen sind ausschließlich mit dem Händler abzuwickeln.

Please read the instructions carefully prior to installing or applying this device. Otherwise, the safety functions of the item could be impaired. Please keep the instructions in a safe place for future reference.

0+

Safety notes:

- Caution! Danger of falls and injury in the event of non-compliance!
- Please only use it for its intended purpose.
- Do not continue to use if it appears defective.
- Caution: Use under direct adult supervision. Do not leave children to play without supervision. Caution when using! Skill is required to avoid falls and collisions that may lead to injuries.
- The maximum user weight is 100 kg.
- Only use the article inside.
- Use the item on a dry and level surface.
- Make sure that there is enough space around the article. There should be no objects or obstacles in this space.
- Only allow children to use the article with bare feet or with slip-proof socks or shoes.
- Pointed or sharp objects could damage the article. Ensure that the play area is free from such objects.

Cleaning:

Clean the item with a slightly dampened cloth. Do not use corrosive or abrasive cleaning products. Dry thoroughly before further use.

Storage:

Store the item in a dry place. Protect the item from direct sunlight. Keep the item out of the reach of children.

Please keep the purchase document, instructions for use and article number safe. Guarantee claims or other warranty claims must be arranged exclusively with the retailer.